

STANDARD NOTES FOR UTILITY INSTALLATION

1. Call "Miss Utility" at 1-800-257-7777 48 hours prior to the start of work.
2. Only enough trench should be excavated which can be backfilled daily.
3. Excavated trench materials should be placed on the high side of the trench.
4. Immediately following utility installation, the trench shall be backfilled, compacted and stabilized at the end of each working day. No more trench shall be opened than can be completed in the same day.
5. Full trench compaction is required.
6. Mulching to Cecil SCD specifications of all disturbed areas and daily on backfill will be required.
7. Any sediment control practices which are disturbed during utility construction shall be repaired or replaced at the end of each working day.
8. Any ditches or drainage ways disturbed during construction will be restored to original condition.